

PSC Headphone Distribution Amplifier

Instructions

1. Remove slide-out battery holder and insert a fresh 9V Alkaline battery, being careful to match the polarity to the drawing inside the battery holder.
2. Slide the battery holder back into the rear of the unit until it clicks. For battery operation, set the front panel power switch to "BATT". The LED will light green with a good battery and will turn red when the battery is getting low. Battery life is estimated at 7-10 hours.
3. For external powering, set the power switch to "EXT" and plug in an optional AC/DC adapter at 6-15 Volts, 100 mA or greater. The center pin is Positive.
4. Plug an audio signal into the "Input" jack on the back side of the unit with a standard ¼" stereo phono plug. Now you can connect up to 4-headphones to the output jacks on the back and control the volume level individually with the front panel volume controls.

END